

## Trekkenplan Singer Theater

Trek nr.	Afst. KK	Omschrijving	HM.	TM	LM	bijzonderheden
vd	-140					
SL.trek	-120					
1	40					
2	60	<b>Poten 1</b>				
3	80	<b>Fries 1</b>				
4	100					
5	120					
6	140					
7	160					
8	180					
9	200					
10	220	<b>Fries 2</b>				
11	240	<b>Poten 2</b>				
12	260					
13	280					
14	300					
15	320					
16	340					
17	360					
18	380	<b>Fries 3</b>				
19	400	<b>Poten 3</b>				
20	420					
21	440					
22	460					
23	480					
24	500					
25	520					
26	540	<b>Fries 4</b>				
27	560	<b>Poten 4</b>				
28	580					
29	600					
30	620					
31	640	<b>Horizonbatterij</b>				
32	660					
33	680					
34	700					
35	720	<b>Fries 5</b>				
36	740	<b>Poten 5</b>				
37	760	<b>Fond</b>				
38	780	<b>Horizondoek</b>				